





Instruction Manual

MIKA DRESSER 11722951



DISTRIBUTOR:

BOPITA


Energieweg 1, 6662 NS Elst

The Netherlands

www.bopita.com

25.04.2022


15



QC-CODE


(UK) for service requests
 (NL) voor service vragen
 (FR) pour les demandes de service
 (DE) für Service Anfragen
 (ES) para consultas de servicio
 (IT) per richieste di assistenza

QC-CODE







16





1





2





3





11



12



5



6

